





NL - Aansluitingen externe vrijgave – tankleegmelding DIGI pomp > 07-2025		
bedrijfsstand	omschrijving	Parameters
EU.xx	Externe vrijgave 0 = laag actief (standaard setting), met een open ingang wordt de pomp vrijgegeven. Wordt de ingang geactiveerd (contact gesloten) stopt de pomp en verschijnt er op het display “STOP” . 1 = hoog actief, met open ingang is de pomp geblokkeerd en toont het display “STOP” , wordt de ingang geactiveerd (contact gesloten) wordt de pomp vrijgegeven.	 <i>Stuursignaal tussen blauw en bruin</i>
tL.xx	Tank leegmelding 0 = laag actief, met open ingang verschijnt er op het display “LO” 1 = hoog actief (standaard setting), met gesloten ingang verschijnt er op het display “LO”	 <i>Stuursignaal tussen zwart en wit</i>
EN - Connections external release – tank empty notification DIGI pump > 07-2025		
mode	description	parameters
EU.xx	External release 0 = low active (default setting), with an open input the pump is released. If the input is activated (contact closed) the pump stops and “STOP” appears on the display. 1 = high active, with open input the pump is blocked and the display shows “STOP” , when the input is activated (contact closed) the pump is released (no specific message text on the display)	 <i>Control signal between bleu and brown</i>
tL.xx	Tank empty notification 0 = low active, with open input the display shows “LO” 1 = high active (default setting), with closed input the display shows “LO”	 <i>Control signal between black and white</i>